

# **Operating instructions**

for solenoid valve of the series

Typ 210 Typ 210a Typ 214 Typ 215 Typ 216 Typ 220 Typ 220 Typ 221 Typ 240 Typ 242 Typ 246 Typ 310 Typ 314 Typ 317

Read carefully before use. Store in a safe place for future reference. Subject to technical modifications.



## **Table of contents**

1	Abo	out these instructions	4
	1.1	Target group	4
	1.2	Other applicable documents	4
	1.3	Guarantee	4
	1.4	Warning notices and symbols	5
2	Gen	eral safety instructions	6
	2.1	Intended use	6
	2.2	General safety instructions	6
	2.	2.1 Duties of the operator	6
	2.	2.2 Duties of the personnel	7
	2.3	Special dangers	7
	2.	3.1 Duties of the personnel	7
3	Desi	ign and function	8
	3.1	Type label	8
	3.2	Description	9
	3.3	Design 1	.0
	3.	3.1 Type 210	.0
	3.	3.2 Type 210a 1	.0
	3.	3.3 Type 214 1	.0
	3.	3.4 Type 215 1	.1
	3.	3.5 Type 216	.1
	3.	3.6 Type 220 1	.1
	3.	3.7 Type 221 1	.2
	3.	3.8 Type 240 1	.2
	3.	3.9 Type 242 1	.2
	3.	3.10 Type 242 FL	.3
	3.	3.11 Type 246	.3
	3.	3.12 Type 310	.3
	3.	3.13 Type 314 1	.4
	3.	3.14 Type 317 1	.4
4	Trar	nsport, storage and disposal1	.5
	4.1	Unpacking 1	.5
	4.2	Transport 1	.5
			_



	4.3	Sto	rage	15
	4.4	Dis	posal	16
5	Inst	tallat	ion and connection	17
	5.1	Pre	paring the installation	17
	5	.1.1	Checking conditions of use	17
	5.2	Pla	nning pipelines	17
	5	.2.1	Designing pipelines	17
	5.3	Fitt	ing the valve to a pipeline	18
	5	.3.1	Threaded connection	18
	5	.3.2	Connection with flange	18
	5.4	Ele	ctrical connection	19
	5	.4.1	Plug assignment	19
	5.5	Car	ry out a pressure check	19
6	Ор	erati	on	20
	6.1	Cor	nmissioning	20
7	Ma	inter	nance and repairs	20
	7.1	Ma	intenance	21
	7.2	Rep	pairs	21
	7	.2.1	Removing valves	21
	7	.2.2	Replacing solenoid coils	22
	7.3	Spa	re parts	23
	7.4	Ret	urns	23
	7.5	Рас	kaging	23
8	Fau	ılt eli	mination	24
9	Арј	bend	ix	25
	9.1	Тес	hnical data	25
	9.2	Circ	uit diagrams	25
	9	.2.1	Circuit diagrams Type 210 / 210a / 214 / 216	25
	9	.2.2	Circuit diagrams Type 220 / 221 / 240 / 242 / 246	26
	9	.2.3	Circuit diagrams Type 310 / 314 / 317	26
	9.3	Dec	laration of conformity	27



## **1** About these instructions

These instructions

- Are part of the valve
- Are applicable for Series 210, 210a, 214, 215, 216, 220, 221, 240, 242, 246, 310, 314 and 317
- Describe the safe and correct operation of the valve
- Are available for downloading from the website

## 1.1 Target group

#### Operator

- These instructions must be kept available at the place of use, including for future applications.
- Employees must be encouraged to read and observe these instructions.
- Additional country-specific or plant-specific regulations and rules must be observed.

#### Personnel

- Skilled workers with additional qualifications for installing the respective pipeline system.
- Electrician
- Read these instructions as well as all other applicable documents.

## **1.2** Other applicable documents

Data sheet

If not available, the data sheet must be requested from the manufacturer.

## 1.3 Guarantee

AWS accepts no liability if operators or third parties:

- Disregard this document
- Do not use the product properly
- Carry out interventions of any type whatsoever to the product (alterations, modifications, etc.)

Malfunctions that can be attributed to contamination or wear, as well as wearing parts (e.g. seals), are not covered by the warranty.



## **1.4** Warning notices and symbols



WARNING
<b>Medium risk</b> Denotes a possibly dangerous situation that may result in serious injuries or death if not avoided.





## NOTE

**Instruction** Denotes a possibly dangerous situation that may cause damage to property if not avoided.



## **2** General safety instructions

Liability



#### NOTE

The manufacturer accepts no liability for damage resulting from the failure to observe the complete documentation.

#### 2.1 Intended use

- The valve must be used exclusively for shutting off pipelines carrying suitable media
- Observe the operating limits
- Use the armature exclusively for media that are free of solid matter

#### 2.2 General safety instructions



Information Read and observe the following regulations before carrying out any activities.

NOTE

#### 2.2.1 Duties of the operator

#### Safety-conscious working

- Only operate the value if it is in technically flawless condition, for its intended application and keeping safety and potential dangers in mind in accordance with these instructions.
- Ensuring adherence and supervision:
  - Intended use
  - Statutory or other safety and accident-prevention regulations
  - Safety regulations for handling dangerous substances
  - Applicable standards and directives of the respective country of use
- Supply personal protective equipment



#### **Personnel qualifications**

- Make sure that personnel tasked with carrying out activities using the valve have read and understood these instructions and all other applicable documents before starting work, especially safety, maintenance and repair information.
- Manage the responsibilities, competencies and supervision of personnel.
- Only qualified technical personnel are to be permitted to carry out the following work:
  - Installation, repair and maintenance work
    - Work on the electrical system
- Only allow trainee personnel to work on the valve under the supervision of qualified technical personnel



## WARNING

**Unqualified personnel** Improper handling can result in serious personal injuries or damage to property. The work described here must only be carried out by qualified personnel.

#### 2.2.2 Duties of the personnel

- Instructions on the valve itself should be observed and kept in a legible state, e.g. type label.
- Only work on the valve if the following prerequisites are met:
  - System is drained
  - System is flushed
  - System is de-pressurised
  - System is cooled
  - System is secured against reactivation
- Do not make modifications to the device

### 2.3 Special dangers

#### 2.3.1 Duties of the personnel

- When handling dangerous media (e.g. hot, flammable, explosive, toxic, harmful, environmentally hazardous), always observe the safety regulations governing the handling of dangerous substances.
- During all work on the valve, wear personal protective equipment.
- Leakages and residues must be safely contained and disposed of in an environmentally-safe manner.



## **3** Design and function

## 3.1 Type label



Layout of the type label: (similar picture)

- 1 Article
- 2 Supply voltage
- 3 Connection
- 4 Nominal diameter
- 5 Medium temperature
- 6 Commission number
- 7 Pressure range
- 8 Serial number
- 9 Date of manufacture



## 3.2 Description

The metal value is a seat value and is used for opening and closing pipelines. It is fully automatic and glandless and therefore practically maintenance-free.

- Available as normally closed (NC) or normally open (NO) variants.
- Connector complies with DIN EN 175301-803 form A.
  - Type 210 and Type 310 with DIN EN 175301-803 form B
- Flow direction as per direction arrow on the valve body.
- Valves are not suitable for back pressure.
- Fitting position:
  - Solenoid coil ideally at the top.
  - Fit valve horizontally or vertically into the line.

#### Typ 210 / 210a / 214 / 215 / 216

The valve is a direct-controlled seat valve. No differential pressure is required for opening or closing.

#### Тур 246

The valve is a servo-controlled seat valve with plunger and requires a differential pressure to open and close of 0,5 bar between inlet and outlet.

#### Type 220/240

The valve is servo-controlled and requires a differential pressure to open and close. Type 220 requires a differential pressure of 0.1 bar between the inlet and outlet. Type 240 requires a differential pressure of 0.5 bar between the inlet and outlet.

#### Type 221/242

The valve is servo-controlled with positive lift. No differential pressure is required for opening and closing.

#### Тур 310 / 314 / 317

The valve is a direct-controlled seat valve. No differential pressure is required for opening or closing.



## 3.3 Design

## 3.3.1 Type 210



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Valve body	Brass or stainless steel
	Seal material	NBR, EPDM or FKM

## 3.3.2 Type 210a



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Valve body	Brass
	Seal material	NBR, EPDM or FKM

3.3.3 Type 214



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Valve body	Brass or stainless steel
	Seal material	NBR, EPDM or FKM



## 3.3.4 Type 215



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Valve body	Brass or stainless steel
	Seal material	NBR, EPDM or FKM

3.3.5 Type 216



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Valve body	Brass or stainless steel
	Seal material	NBR, EPDM or FKM

3.3.6 Type 220



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Cover	Brass or stainless steel
4	Valve body	Brass or stainless steel
	Seal material	NBR, EPDM or FKM



## 3.3.7 Type 221



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Cover	Brass or stainless steel
4	Valve body	Brass or stainless steel
	Seal material	NBR, EPDM or FKM

3.3.8 Type 240



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Cover	Brass or stainless steel
4	Valve body	Brass or stainless steel
	Seal material	NBR, EPDM or FKM

3.3.9 Type 242



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Cover	Brass or stainless steel
4	Valve body	Brass or stainless steel
	Seal material	NBR, EPDM or FKM



## 3.3.10 Type 242 FL



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Cover	stainless steel
4	Valve body	stainless steel
	Seal material	NBR, EPDM or FKM

## 3.3.11 Type 246



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Cover	Brass or stainless steel
4	Valve body	Brass or stainless steel
	Seal material	NBR, EPDM or FKM

3.3.12 Type 310



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Cover	Brass or stainless steel
4	Valve body	Brass or stainless steel
	Seal material	NBR, EPDM or FKM



## 3.3.13 Type 314



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Valve body	Brass or stainless steel
	Seal material	NBR, EPDM or FKM

## 3.3.14 Type 317



POS	Designation	Material
1	Connector	Plastic
2	Coil housing	Plastic or metal
3	Valve body	Brass or stainless steel
	Seal material	NBR, EPDM or FKM





## 4 Transport, storage and disposal

## 4.1 Unpacking

- On receipt of the valve, unpack it, check it for signs of transport damage and ensure that it is complete.
- Transport damage or missing components must be reported to the manufacturer immediately.
- Make sure that the type label information matches the order and design data.
- When installing the product, dispose of the packaging material in accordance with the applicable local regulations.

### 4.2 Transport

- Wherever possible, transport the valve in the original packaging
- Lift the valve by hand for transport purposes (see data sheet for weight information)

#### 4.3 Storage



You must ensure that the storage location fulfils the necessary conditions, such as:

- Dry
- Frost-free
- Free from vibrations
- No direct sunlight
- Storage temperature range +10°C to +50°C



## 4.4 Disposal

	NOTE
	Contamination
<b>▲</b>	Plastic components may be contaminated by toxic or radioactive
	media to such an extent that cleaning is not sufficient.

 WARNING
<b>Danger of poisoning and environmental damage from the medium</b> During all work on the armature, wear personal protective equipment. Prior to disposing of the valve, contain any leaking medium and
dispose of it separately in accordance with the applicable local regulations. Medium residues in the armature must be neutralised. Dismantle plastic parts and dispose of them in accordance with the applicable local regulations.

The valve must be disposed of in accordance with the applicable local regulations.



## 5 Installation and connection

### 5.1 Preparing the installation

#### 5.1.1 Checking conditions of use

- Make sure that the valve design is suitable for the intended use:
  - Materials used
  - Medium
- Ensures the necessary conditions of use
  - The resistance of the materials used for the body and seals against the medium
  - Media temperature
  - Operating pressure
- Agree any other use with the manufacturer

### 5.2 Planning pipelines

#### 5.2.1 Designing pipelines



#### WARNING

**Danger of poisoning and environmental damage from the medium** Leakage due to leaks caused by impermissible pipeline forces. Make sure that no tensile or compressive forces and no bending moments act on the armature.

- Plan pipelines with safety in mind
  - Ensure there are no tensile or compressive forces
  - Ensure there are no bending moments
  - Compensate for changes in length caused by temperature fluctuations
  - Observe the direction of flow
  - Pay close attention to the fitting position and direction of the valve
  - Apply suitable measures to prevent pressure surges
  - Dimensions (3.3 Design and dimensions)
- Fit dirt traps to ensure proper functioning



## 5.3 Fitting the valve to a pipeline

### WARNING

#### De-pressurised fitting.

Only fit the valve to de-pressurised pipelines.



**Danger of poisoning and environmental damage from the medium** Leakage due to incorrect installation. Installation work on the pipelines must only be carried out by skilled

WARNING

workers who are trained for the respective pipeline system.



NOTE

**Improper installation of the valve can cause damage to property** Fit the armature horizontally or vertically.

Ideally, fit the armature with the solenoid coil pointing upwards.



#### NOTE

**Contamination in the valve can cause damage to property** Make sure that no contamination can enter the armature. Flush the pipeline with a neutral medium.

The procedure used to fit the armature is determined by the type of connection to the pipeline.

#### 5.3.1 Threaded connection

- Screw the threaded connection onto the pipe in accordance with the applicable standard.
- Use suitable sealing materials depending on the design and intended purpose.

#### 5.3.2 Connection with flange

- Check that the sealing face is free of damage and clean.
- Carefully align the flange in front of the threaded joint.
- Centre the seals (use suitable sealing material).
- Connect the valve flange and pipe flange with the seal and suitable bolts.
- Tighten the bolts cross-wise. Use all of the flange holes!
- Only use permissible joining elements.



## 5.4 Electrical connection



## DANGER

Danger to life due to electric shock

Only allow an electrician to work on the electrical system. Switch off the power supply to the system and secure it to prevent it from being accidentally switched on again. Connect protective conductors.

- Before making the electrical connection, check that the current type and voltage are correct (see data sheet).
- Make sure that the device plug connection is protected against constant moisture. If necessary, fit a protective cover.
- Connect the cable to the device.
- Connect protective conductors.
- Insert device plug into connector on the valve.

#### 5.4.1 Plug assignment





- 1 Supply voltage
- 2 Supply voltage
- 3 Protective earth conductor

### 5.5 Carry out a pressure check



- Pressurise the valve. When doing so, ensure that:
  - Test pressure < permissible system pressure
  - Test pressure < 1.5 PN
- Check that the valve is leak-tight.



## 6 **Operation**

## 6.1 Commissioning

The valve must be correctly assembled and connected.

WARNING
Danger of poisoning and environmental damage from the medium Leakage due to leaks caused by impermissible pipeline forces. Make sure that no tensile or compressive forces and no bending moments act on the armature.



	V	VARI	NIN	G	

Solenoid and valve body heat up during operation. Risk of burning when touching hot surfaces. Wear protective gloves.



#### NOTE

**Overheating will destroy the alternating voltage solenoids** When commissioning the valve equipped with an alternating voltage solenoid, make sure that the solenoid coil is mounted on the plunger guide.

- Please ensure that the required differential pressure is applied between valve inlet and valve outlet for the corresponding valve types.
- After it is first exposed to pressure and operating temperatures, check that the valve is leak-tight.

## 7 Maintenance and repairs







## 7.1 Maintenance

- Visual and functional inspection (quarterly):
  - No change in normal operating states
  - Leak-tightness
  - No unusual operating noises and vibrations
- If necessary, clean valve with a damp cloth.



## Adjust maintenance intervals

The maintenance intervals must be adjusted in line with the applicable operating conditions. This is the responsibility of the operator.

NOTE

## 7.2 Repairs





### WARNING

**Risk of injury and poisoning due to dangerous or hot media** During all work on the valve, wear personal protective equipment. Any medium leaks must be safely contained and disposed of in an environmentally-safe manner.



### WARNING

**Risk of injury during disassembly work** Wear protective gloves; components can become extremely sharp as a result of wear or damage.

Components fitted with springs must be removed with great care as the spring tension can cause components to be hurled out.

#### 7.2.1 Removing valves

- Make sure that:
  - System is drained
    - System is flushed
    - System is de-pressurised
    - System is cooled
  - System is secured against reactivation
  - Valve de-energized
- Remove valve from the pipeline.
- If necessary, decontaminate valve.
  - Empty spaces in the valve may still contain medium.



#### 7.2.2 Replacing solenoid coils



- 1. Loosen bolt (1) and remove device plug (2) from the valve.
- 2. Unscrew nut (3) and remove washer (4).
- 4. Remove solenoid coil (5). Dispose of faulty solenoid coil correctly.
- 5. Fit new solenoid coil (5).
- 6. Refit the individual parts in reverse order.
- 7. Connect armature to power supply (5.4 Connecting the armature to the power supply).
- 8. Conduct pressure check (5.5 Conducting the pressure check).



## 7.3 Spare parts

- Keep the following information ready for ordering spare parts.
  - Valve type
  - Article number
  - Nominal pressure and diameter
  - Materials of body and seals
- Only use spare parts supplied by AWS Apparatebau.

#### 7.4 Returns

- Seal all valve openings (e.g. with protective film).
- A clearance declaration must be completed and enclosed with the returns.

### 7.5 Packaging



AWS accepts no responsibility for damage caused by the use of unsuitable packaging!



## 8 Fault elimination



## Risk of injury and poisoning by media

During all work on the valve, wear personal protective equipment. Any medium leaks must be safely contained and disposed of in an environmentally-safe manner.

WARNING



## WARNING

Solenoid and valve body heat up during operation. Risk of burning when touching hot surfaces.

Hot surfaces

Wear protective gloves.

Faults that are not mentioned in the table below or which cannot be attributed to the causes specified should be discussed with the manufacturer.

Faults	Cause of fault <sup>1</sup>	Troubleshooting
Valve leaky	Valve seat leaky	Replace valve.
Valve does not close	Nominal voltage is still applied	Check control voltage.
	Incorrectly fitted	Fit armature to the valve in accordance
		with the flow direction.
	Differential pressure	Make sure that the required differential
	between valve inlet and	pressure between the valve inlet and
	valve outlet too low <sup>2</sup>	valve outlet is applied.
	Plunger blocked	Replace armature.
Valve does not open	Operating pressure too high	Check operating pressure and, if
		necessary, set permissible operating
		pressure.
	Supply voltage interrupted	Check power supply.
	or too low	Check cable connection.
	Nominal voltage and coil	Make sure that the valve is suitable for
	voltage do not match	the intended use.
	Solenoid coil faulty	Fit new solenoid coil
		(see 7.2.2).
	Plunger blocked	Replace armature
Medium leaking from	Pipeline connection leaky	Check pipeline connection to the
pipeline connection		armature. If necessary, replace the seal.

1) Faults apply to standard valves (NC) normally closed

2) Applies to Type 220 and 240



## 9 Appendix

## 9.1 Technical data

Please refer to the data sheet for technical data such as the operating pressure or the operating temperature. If the data sheet is not available, request it from the manufacturer.

## 9.2 Circuit diagrams

#### 9.2.1 Circuit diagrams Type 210 / 210a / 214 / 216



Switching function: NC (normally closed)

- Type 215



Switching function: NO (normally open)



### 9.2.2 Circuit diagrams Type 220 / 221 / 240 / 242 / 246



Switching function: NC (normally closed)

- Typ 240 / 242



Switching function: NO (normally open)

#### 9.2.3 Circuit diagrams Type 310 / 314 / 317



Switching function:

NC (normally closed)



### 9.3 Declaration of conformity

## EU - Konformitätserklärung

EU - Declaration of conformity

**Die Firma** *The company*  AWS Apparatebau Arnold GmbH Zimmerbachstraße 51 D - 74676 Niedernhall-Waldzimmern Tel.: +49 7940 9308 – 200 E-Mail: info@aws-apparatebau.de

erklärt in alleiniger Verantwortung als Hersteller, dass für die Produkte unter den folgenden Typenbezeichnungen

declares in own responsibility as manufacturer, that for products with the following type designations

# 210, 210a, 214, 214a, 215, 216, 217, 220, 221, 239, 240, 242, 246, 310, 311, 314

#### die Konformität zu den nachfolgend genannten Richtlinien festgestellt wurde:

the conformity to below mentioned directives has been established:

2014/68/EU – Druckgeräterichtlinie / Pressure Equipment Directive 2014/35/EU – Niederspannungsrichtlinie / Low Voltage Directive 2011/65/EU – RoHS-Richtlinie / RoHS Directive

Ebenso stehen die Ersatzteile für die oben genannten Produkte im Einklang mit den aufgeführten Richtlinien, sofern diese anwendbar sind.

*Likewise, the spare parts for the above mentioned products are in accordance with the listed directives, provided they are applicable.* 

Hinweis in Bezug auf die Druckgeräterichtlinie:

Note regarding the Pressure Equipment Directive:

Die Konformität wurde nach Modul A bewertet.

Bei oben aufgeführten Ventilen ≥ DN 32 handelt es sich um Druckgeräte nach Kategorie I. Diese Ventile dürfen nicht mit instabilen Gasen betrieben werden.

Bei oben aufgeführten Ventilen ≤ DN 25 handelt es sich um Druckgeräte nach Artikel 4, Absatz 3 (Gute Ingenieurspraxis), auf denen bestimmungsgemäß keine CE Kennzeichnung angebracht werden darf.

The conformity has been assessed according to module A.

Above mentioned values  $\geq$  DN 32 are pressure equipment within category 1. These values must not be operated with unstable gases.

Above mentioned values  $\leq$  DN 25 are pressure equipment within article 4, paragraph 3 (sound engineering practice), which must not bear the CE marking.

Niedernhall, 09.06.2021 Ort, Datum Location, date

i.A. D. Zuber Konstruktionsleiter Design Manager

revision status: 24.10.2019

27/30

index number: D0-092



## **Notes**



## Imprint

	Manufacturer	AWS Apparatebau Arnold GmbH		
		Zimmerbachstrasse 51		
		74676 Niedernhall-Waldzimmern		
		Germany		
		Phone:	+49 (0) 7940 9308 200	
		Fax:	+49 (0) 7940 9308 212	
		E-mail:	info@aws-apparatebau.de	
		Website:	www.aws-apparatebau.de	
	Published by	AWS Apparatebau Arnold GmbH		
	,			
	Printed by	AWS Apparatebau Arnold GmbH		
	Translation	These operating instructions in English are a translation of the original German operating instructions. Operating instructions in other languages are also translations of the original German operating instructions. In the event of discrepancies		
		between the different versions, the information contained in the		
		original ope	rating instructions in German shall apply.	

Read carefully before use. Store in a safe place for future reference. Subject to technical modifications.



# AWS Apparatebau Arnold GmbH

www.aws-apparatebau.de

Ihr Partner für:

- > Rückschlagklappen
- > Ventiltechnik
- > Baugruppenmontage

Your partner for:

- > Check-valves
- > Valve technology
- > Apparatus construction

Zimmerbachstrasse 51 74676 Niedernhall – Waldzimmern Phone: +49 7940 9308 – 0 Info@aws-apparatebau.de Zimmerbachstrasse 51 D - 74676 Niedernhall – Waldzimmern Phone: +49 7940 9308 – 0 Info@aws-apparatebau.de